


AI

WING ARRANGEMENT

AEROFOILS

AI



VAMPIRE Mk9

A2

NOTE:

PART No'S UNDERLINED: THUS
D.OO2144A ARE ALTERNATIVE PARTS
FOR THE STARBOARD WING.


FOR PARTS NOT SHOWN ON
THIS PLATE, SEE PLATES ILLUSTRATING
THE APPROPRIATE SECTION OF THE
WING.

WING, D.OO6715A/5 PORT, D.OO7611A

AEROFOILS

STBD


A2




VAMPIRE Mk9

MAY 52


28.7.48




INNER HINGE BRACKET FOR
OUTBOARD FLAP, D.OOI6OI



OPERATING ROD FOR
INBOARD FLAP, D.OOI739A.
BOLT D.OOI328.
[D.OOI740A SIMILAR]



OUTER HINGE BRACKET FOR
OUTBOARD FLAP, D.OO2O85.
(D.OO93 & D.OO94, SIMILAR.)



JOINT FITTING AT RIB NO.1,
D.OO3I64 PORT, D.OO3I65 ST'BD.

A3


AEROFOILS
WING FITTINGS

A3


29.7.48.




LEVER FOR FLAP INDICATOR TRANSMITTER
LINK IN ST'BD WING, D.OO430A



HINGE BRACKET FOR WHEEL
DOOR, D.OO1025A




LINK FOR FLAP INDICATOR TRANSMITTER
IN ST'BD WING, D.OO1474A



SPINDLE FOR PULLEYS AT INNER HINGE
BRACKET, OUTBOARD FLAP, D.OO1602



TRUNNION FOR FLAP JACK D.OO1660A




BRACKET FOR WHEEL DOOR
OPERATING MECHANISM D.OO1827

A4


AEROFOILS WING FITTINGS

A4


31.7.48.




BRACKET FOR WHEEL DOOR
OPERATING MECHANISM, D.OOI825
PORT, D.OOI826 ST'BD.




SUPPORT BRACKET FOR TORQUE TUBE
D.OOI777A PORT, D.OOI778A ST'BD.




TRUNNION FOR DIVE BRAKE FLAP JACK;
D.OO2319A PORT, D.OO2320A ST'BD.
BUSH D.OO2322.



FORK END FOR FLAP JACK, D.OOI663.
BOLT D.OOI769
(D.OO2323 SIMILAR)



SPINDLE FORAILERON CONTROL
CABLE PULLEY, D.OO2097.



SIDE PLATE FOR JACK
TRUNNION, D.OOI655A.
(D.OOI656A OPP. HAND)

A5

AEROFOILS WING FITTINGS

A5


9.8.51




STOP FOR WHEEL
DOOR, D.OO1179




SHACKLE FOR FLAP JACK
FORK-END, D.OO1664




SUPPORT BRACKET AT
RIB NO.2 FOR AIR
SUPPLY PIPE, R.OO220A




BRACKET FOR COMPRESSION
LEG PICK-UP, G.OO1010.
SHIM D.OO6975



FRONT FITTING AT COMPRESSION LEG
PICK-UP BRACKET, G.OO1759
BOLT G.OO1743
PACKING PIECE G.OO1017.
[G.OO1761 SIMILAR.]



HOUSING, FOR PLUNGER, WHEEL DOOR LOCK
OPERATING MECHANISM, REAR, G.OO428A.
[G.OO427A SIMILAR.]




BRACKET FOR RADIUS ROD
PICK-UP, G.OO79.

A6

AEROFOILS WING FITTINGS

A6

26.8.48




TORQUE TUBE BETWEEN FLAPS, D.OOI7O3A PORT,
D.OOI7O4A ST'BD. BOLT D.OOI329

A7


AEROFOILS
WING FITTINGS

A7


31.8.48




GUARD FOR AILERON
CONTROL CABLE, D.OO2086




SPINDLE FOR AILERON
OPERATING PULLEY,
D.OO460




CAP OVER BALL-RACE AT
AILERON OPERATING PULLEY
SPINDLE, D.OO4231




BOLT AT AILERON OPERATING
PULLEY FOR LINK, D.OO346



AILERON OPERATING LINK,
D.OO4860A




HOUSING, BALL-RACE BEARING,
IN AILERON INNER HINGE
BRACKET, D.OO6695



ADJUSTMENT QUADRANT FOR
AILERON TAB CONTROL ROD,
D.OO1814 A



GUIDE PLATE FOR AILERON
BALANCE AND OPERATING
CABLES AT PULLEY, D.OO4227




TENSION SPRING FOR DROP
TANK JETTISON CONTROL
CABLE, S.OO279

A8


AEROFOILS WING FITTINGS

A8


31.8.48



GUARD FOR AILERON OPERATING PULLEY,
D.OO4221A PORT, D.OO4222A ST'BD.



AILERON OPERATING PULLEY,
D.OO463 PORT, D.OO462 ST'BD. BOLT D.OO348




BRACKET AND LEVER AILERON INNER HINGE,
D.OOI823 PORT, D.OOI824 ST'BD.

A9


AEROFOILS
WING FITTINGS

A9


1.9.48




JUNCTION BLOCK AT RIB NO.6
FOR PIPES TO JETTISON TANK,
P.OOI180A



AILERON CENTRE HINGE
BRACKET D.OOI07
(D.OOI04 SIMILAR)



LINK BRACKET FOR AILERON
CENTRE HINGE D.OOI08A
(D.OOI05A SIMILAR)



NAVIGATION LAMP,
D.OO6541A PORT, D.OO6542A ST'BD

AIO

AEROFOILS WING FITTINGS


AIO

A11

TAIL UNIT ARRANGEMENT

AEROFOILS

A11




MAY 52

AI2

AEROFOILS ELEVATOR JOO601A/5

AI2

MAY '52




A13


AEROFOILS

FIN AND BOOM, J001007A PORT, J001008A STARBOARD.

A13



301148



1.12.48

A14

AEROFOILS RUDDER J.OO583A/I


A14

A15


AEROFOILS
TAILPLANE 12TPIA

A15

MAY '52








BI

ALIGHTING GEAR MAIN UNDERCARRIAGE ARRANGEMENT

BI




MAY '52

B2

ALIGHTING GEAR

B2

FAIRING, WHEEL DOOR & OPERATING MECH. MAIN UNDERCARRIAGE




MAY'52

B3

ALIGHTING GEAR

B3

RADIUS ROD, MAIN UNDERCARRIAGE, G.001094A/I PORT, G.001095A/I ST'BD




28.2.49

B4

ALIGHTING GEAR NOSE WHEEL ARRANGEMENT

B4



B5

ALIGHTING GEAR

COMPRESSION LEG NOSE WHEEL 12 UN 165A/ND

MAY 52


B5

B6


FAIRING, WHEEL DOOR & OPERATING MECH, NOSE WHEEL

ALIGNING GEAR

B6



3.3.49



B8

ALIGHTING GEAR TOP STRUCTURE, NOSE WHEEL


B8

D1

CONTROLS ENGINE CONTROLS IN FUSELAGE

D1

MAY 52



ENGINE CONTROLS ON FIREPROOF
BULKHEAD, SEE PLATE No.D3

VAMPIRE Mk9


D2

CONTROLS


CONTROL BOX L00750A/2

D2

13349



VAMPIRE Mk9




MAY '52

D3

CONTROLS ENGINE CONTROLS ON FIREPROOF BULKH'D

D3



D4

CONTROLS

FLYING CONTROLS IN FUSELAGE

D4

D5

FLYING CONTROLS IN FUSELAGE (COCKPIT)

CONTROLS

D5

CABLE SEAL
 FERRULE K.OO214.
 HALF WASHER K.OO217.
 LEATHER GLAND
 WASHER K.98646.
 FELT GLAND
 WASHER K.98647.
 GRUB SCREW FOR
 LOCKING SEALS
 K.OO528

SEE PLATE No.D6

K.OO936A LH.

SEE PLATE No.D6

PULLEY
 AS.104


PULLEY
 AS.104


K.OO98A RH.

SEE PLATE No.D8

SEE PLATE
 No.D7

26.7.49






MAY'52

D6


CONTROLS FUSELAGE FITTINGS

D6


9.8.51



BRACKET ON BULKH'D No.2 RH.
12 CF. 291




BRACKET ON BULKH'D No.2
Q.OO73 LH., Q.OO74 RH.




CON. ROD, ELEVATOR TORQUE LEVER TO
QUADRANT, K.OO93A


FRONT
K.OO587A LH.
K.OO588A RH.
REAR
K.OO589A LH.
K.OO590A RH.



ELEVATOR CONTROL PULLEY QUADRANT
K.OO89A/1 LH., K.OO90A/1 RH.



ELEVATOR LEVER
K.OO65A LH. K.OO66A RH.




STAY TUBE, ELEVATOR QUADRANT TO
BULKH'D No.2 K.OO523A

D7


CONTROLS FUSELAGE FITTINGS

D7


19.7.49




FLANGED COUPLING
K.OO172




AILERON CABLE SEAL
GUIDE, AT BOTTOM OF
CONTROL COLUMN, K.OO271A




CONTROL COLUMN SUMP
DRAIN CAP K.OO203.
WASHER AS.119




CONTROL COLUMN SUMP
K.OO46A




CONTROL COLUMN GAITER
K.OO269A



CON. ROD, BRAKE
DIFFERENTIAL UNIT,
K.OO302A



MOUNTING PLATE, BRAKE
DIFFERENTIAL UNIT,
Q.OO99




LEVER ON BRAKE
DIFFERENTIAL UNIT,
K.OO298

D8

CONTROLS FUSELAGE FITTINGS

D8




MAY '52

D9

CONTROLS CONTROL COLUMN K.OO3A/4

D9




20.7.49

DIO

CONTROLS

RUDDER PEDAL ARRANGEMENT

DIO




D11

CONTROLS FLYING CONTROLS IN BOOMS

D11


9.8.51



RUDDER BALANCE LEVER
K.OO339A



STOP BOLT
J.OO1659



SUPPORT BRACKET, ELEVATOR
AND RUDDER LEVER,
J.OO604




STOP BOLT
J.OO1899




BUSH, STOP BOLTS,
J.OO255




LINK PLATE
K.OO362




ROD, ELEVATOR CONTROL AND
BALANCE WEIGHT,
K.OO379A




ROD, CONNECT RUDDER LEVERS
J.OO260A




HINGE BRACKET, RUDDER
TORQUE TUBE, J.OO602A




RUDDER CONTROL LEVER
K.OO344A



ELEVATOR CONTROL LEVER
K.OO346A



RUDDER OPERATING LEVER
J.OO1793A



WEIGHT RUDDER BALANCE LEVER,
K.OO398A



SPIGOT J.OO875




ANGLE BRACKET
J.OO268

D12


CONTROLS BOOM FITTINGS

D12


27.7.49




BRACKET, ELEVATOR TRIM CONTROL,
KOO377A




SHACKLE ON ELEVATOR LEVER
K.OO559A




LINK PLATE KOO376




SPINDLE KOO364



DISTANCE PIÉCE
K.OO375




RUDDER CONTROL LEVER KOO469A.
[ELEVATOR CONTROL LEVER
K.OO472A, SIMILAR]



TOP BRACKET KOO351



CABLE GUARD PLATE RH.
KOO372



CABLE GUARD PLATE LH.
K.OO371

D13

CONTROLS BOOM FITTINGS

D13

21.7.49




GUIDE
KOO533A




SPIGOT
K.OO100



SPIGOT
K.OO99



BRACKET AT FALSE SPAR
K.OO286 ST BD, K.OO287 PORT



SUPPORT, ELEVATOR ELASTIC
CORD ANCHORAGE K.OO407A




FAIRLEAD
K.OO579
FRONT




FAIRLEAD
K.OO577
INTERMEDIATE




FAIRLEAD
K.OO262
REAR




FAIRLEAD K.OO258
INTERMEDIATE



FAIRLEAD K.OO263,
FRONT, PORT BOOM



FAIRLEAD K.OO264,
FRONT, ST'BD BOOM




FAIRLEAD K.OO259
REAR

D14

CONTROLS BOOM FITTINGS

D14



D15


CONTROLS FLYING CONTROLS ON RIB No.1

D15



F1


FUEL SYSTEM PIPES AND FITTINGS IN FUSELAGE




F1

9.8.51


MAY '52




PIPE, FILTER TO PORT PUMP,
POO1821A




PIPE, WING TANKS TO FIREWALL,
POO3479A




PIPE, BOOSTER PUMP TO FIREWALL,
POO3469A



MAIN TANK ADAPTOR
POO2560



MAIN TANK ADAPTOR
POO1823



CONNECTION, PILLAR,
POO104



ELBOW
POO108



PILLAR, BANJO,
POO2688



CLIP, TRANSFER
PIPE SUPPORT,
POO127



CLIP, PUMP DRAIN,
LOO1158A



CLIP, PUMP DRAIN,
POO2183A




CLIP, VENT
PIPE SUPPORT,
LOO201A LH.
LOO201A MK.2 RH.

F2

FUEL SYSTEM

PIPES AND FITTINGS IN FUSELAGE

F2




F3

FUEL SYSTEM


PIPES AND FITTINGS IN FUSELAGE (FUSELAGE TANK)

F3

9.8.51




BRACKET, SUPPORT,
P.OO167A




PLATE, RETAINING,
A.OO1300




NUT CAP
P.OO2561
(P.OO203 SIMILAR)




DISC, RETAINING,
P.OO2563



BANJO
P.OO1184




CONNECTION
P.OO437




BANJO
P.OO2559




BRACKET, SUPPORT,
P.OO2784A




ELBOW RH.P.OO3383A
ELBOW LH.P.OO3384A



STRUT, SUPPORT,
P.OO242A/1



PLATE, SUPPORT,
P.OO2781A



ADJUSTER,
TANK STRAP,
P.OO166




TRUNNION
P.OO163, LH. THREAD,
P.OO164, RH. THREAD

F4

FUEL SYSTEM

F4

PIPES AND FITTINGS IN FUSELAGE (FUSELAGE TANK)




F5

FUEL SYSTEM


FUSELAGE TANK FITTINGS

F5


9 8 51




PLATE, BOLT, POO2288A.
(POO2289A SIMILAR)




PLATE, BOLT,
POO2285A




CAP, FILLER, POOI152A.
SEALING WASHER 691234




RING, SEALING,
POO2623



ELBOW, FUEL FEED,
POO3429A



RING, SEALING,
POO217




PLATE, BOLT,
POO2741A



SOCKET, EARTHING,
POOI52



ADAPTOR
POO58



PLATE, BOLT, POOI54A.


F6

FUEL SYSTEM FUSELAGE, TANK FITTINGS

F6


FUEL SYSTEM

PIPES AND FITTINGS IN WING




MAY'52


CLAMP BLOCKS



POO263A PORT
POO264A ST'BD




POO2584A




POO2588A

POO723 PORT
POO724 ST'BD



POO725 PORT
POO726 ST'BD




POO733



CLIP
POO1901


POO1814



POO1815



PLUG, BLANKING,
POO884.



ADAPTOR
POO1189



PLUG, BLANKING,
POO741.

F8

FUEL SYSTEM
WING FITTINGS

F8


F9

100 GALLON AIRSHIP DROP-TANK

FUEL SYSTEM


F9


MAY '52






G1


FUSELAGE
COMPLETE




TRAY, ACCUMULATOR MOUNTING, INNER,
B.OOI15A



MOUNTING, CAMERA AND RADIO,
12 UN105A




TRAY, ACCUMULATOR
MOUNTING, OUTER,
B.OOI13A LH. B.OOI14A RH.



SPRING
B.OOI42

FRAME, ACCUMULATOR
MOUNTING SUPPORT,
B.OOI09A LH, B.OOI10A RH.



SPRING
A.OOI311

STEP A.OOI306A/1

MAIN SPRING
A.OOI310

ASSEMBLY OF PILOT'S ACCESS STEP


19.2.51

G2

FUSELAGE FITTINGS IN FUSELAGE

G2

19.2.51




BRACKETS, CANNON
DOOR, A.OO413A
AND A.OO414A



BRACKET, NOSE
WHEEL DOOR,
A.OO633




BRACKET,
ACCUMULATOR
MOUNTING
B.OO108A




BRACKET,
ACCUMULATOR
MOUNTING,
B.OO107A




ADAPTOR R.OO178A



BRACKET LH.
ACCUMULATOR
MOUNTING, B.OO112A
BRACKET RH. B.OO111A



BRACKET,
NOSE WHEEL DOOR,
A.OO1124A




BRACKET, NOSE
WHEEL WELL,
A.OO1416




STRUT, CAMERA
MOUNTING SUPPORT,
B.OO943




EYEBOLT,
FIREPROOF
BULKH'D, A.OO4221
(A.OO4220 SIMILAR)



BRACKET,
FIREPROOF BULKHEAD,
L.OO168A



BRACKET, NOSE WHEEL DOOR,
A.OO1363



BRACKET,
FIREPROOF
BULKHEAD,
L.OO169A

G3

FUSELAGE FITTINGS IN FUSELAGE

G3

CANOPY RUNNER
A.OO4959A LH.
A.OO4960A RH.

CANOPY SEALING MEMBER
A.OO4965A LH.
A.OO4966A RH.

CANOPY RAIL
A.OOI675 LH.
A.OOI676 RH.

CANOPY A.OO4929A
COMPLETE.
CANOPY PERSPEX
A.OO4933A.

HOUSING, CANOPY
STOP, A.OO4764A

PLATE, CANOPY
STOP, A.OO2206

CANOPY
RAIL
LATCH
A.OOI677A LH.
A.OOI678A RH.

SECTION THROUGH CANOPY

WINDSCREEN A.OO4774A

FAIRING
A.OO2165A

WINDSCREEN A.OO5189 LH.
A.OO5190 RH.

COCKPIT CANOPY DETAILS

PLUNGER, CANOPY
STOP, A.OO4768.
SPRING, A.OO4769

GEAR BOX (COMPLETE)
A.OO2053A/13

PINION A.OOI13

PLUNGER
A.OOI02

SHAFT A.OO98

COCKPIT CANOPY
WINDING GEAR

PLATE A.OO7269

LINK A.OOI04

GEAR WHEEL
A.OOI665

GASKET A.OOI16

SPRING A.OOI08

HANDLE
(COMPLETE)
A.OO7267A
SCREW A.OOI06

BRACKET AND GEARS
(COMPLETE) A.OO526A

FOR DETAILS
SEE
PLATE No.G5

CONNECTING ROD A.OO2004A

CABLE A.OO2318A
CLIP A.OO2320

COCKPIT CANOPY
JETTISON GEAR

CABLE
A.OO4098A

SPRING
A.OO4091

CON. ROD
A.OOI693A




MAY '52

G4

FUSELAGE

G4

CANOPY DETAILS AND WINDING AND JETTISON GEAR

26.4.50			
	PLATE, CANOPY RELEASE KNOB, A.OOI15	SPINDLE, GEAR WHEEL, CANOPY RAIL, A.OOI666	KNOB, OUTSIDE CANOPY RELEASE, A.OO99. SPRING A.OOI09
	LEVER, JETTISON, CANOPY RAIL, A.OO4192A		LEVER, BULKH'D No. 3, A.OOI694A
	LEVER, BULKH'D No.3, A.OO4058A		LEVER A.OO2035A
	STOP, TOP, BULKH'D No. 3, A.OO2176A		BRACKET, JETTISON RELEASE LEVER, A.OOI673 INNER A.OOI674 OUTER
			BRACKET, BULKH'D No. 3, A.OO2024A
			HOUSING, SPINDLE BULKH'D No. 3, A.OOI667


G5

FUSELAGE


G5

CANOPY WINDING AND JETTISON GEAR DETAILS


19.2.51




BRACKET, CANOPY SEAL VALVE,
L.OO567A




N.R. VALVE, CANOPY SEAL,
R.OO35A




INNER AMMUNITION CHUTE
S.OO299A LH, S.OO300A RH.
(OUTER S.OO311A AND S.OO312A SIMILAR)



BRACKET, FASTENER HOOK,
12 F 269A



HOOK 12 F 149



HINGE 12 FS 37
(12 FS 39 SIMILAR)

G6


FUSELAGE

FIREPROOF BULKHEAD AND GUN BAY DOOR DETAILS.


G6

OXYGEN SYSTEM PIPES AND FITTINGS

J1



STRAP Q.002036A LH, Q.002035A RH.



BEARER Q.002037A.




ADAPTOR Q.00138



PLATE Q.00184A


J1



9550




MAY '52



J2

PIPE SERVICES PIPES FOR AIR SPEED INDICATOR

J2




J3

PIPE SERVICES

J3

PIPES IN FUSELAGE (UNDERCARRIAGE AND FLAP)












J4

PIPE SERVICES

PIPES IN FUSELAGE (DIVE BRAKE AND WHEEL BRAKE)

J4

CLAMP BLOCKS			9.550
			
QOO321A	QOO136A	QOO839A	
			
QOO324A	QOO108A	QOO280	
			
QOO239	QOO278	QOO235A	
			
QOO229A	QOO472	QOO599	QOO240
			
ANGLE BRACKET QOO563	ADAPTOR, PITOT PIPES, QOO331	ANGLE BRACKET QOO813A	


J5

PIPE SERVICES

PIPES IN FUSELAGE (DETAILS)

J5


MAY'52



BRACKET, MOUNTING,
CANOPY SEAL 3 WAY COCK,
Q002106A




ADAPTOR ON BULKHEAD No1
Q00846



BLOCK, JUNCTION, CUT-OUT
VALVE, Q00221



PILLAR Q00219




BLOCK, JUNCTION, CUT-OUT
VALVE, Q00220


PILLAR, Q0097
[Q00225, Q00226, Q00332]
AND Q00333 SIMILAR



ADAPTOR Q0043



BLOCK, ACCUMULATOR,
Q00791A



BLOCK, MOUNTING, ACCUMULATOR,
Q00436A

J6

PIPE SERVICES


PIPES IN FUSELAGE (DETAILS)

J6


J7

PIPE SERVICES
PIPES IN WING AND ON FIREPROOF BULKHEAD


DETAILS ON FIREPROOF BULKHEAD



ADAPTOR Q.OO1010



CLAMP BLOCK
Q.OO728A




BRACKET Q.OO171A



CLAMP BLOCK
Q.OOB48


CLAMP BLOCKS IN WING




Q.OO159A




Q.OO317A



Q.OO251A




- 1 FLAP UP
- 2 FLAP DOWN
- 3 DIVE BRAKE ON
- 4 DIVE BRAKE OFF
- 5 UNDERCARRIAGE UP
- 6 UNDERCARRIAGE DOWN
- 7 BRAKE LH.
- 8 BRAKE RH.
- 9 A.S.I. STATIC
- 10 A.S.I. PRESSURE
- 11 HYD'C PUMP PRESSURE
- 12 HYD'C PUMP SUCTION




- 12 Q.OO2233A/ND
- 11 Q.OO3617A/ND

A FIREPROOF
BULKHEAD




- 4 Q.OO533A/ND
- 3 Q.OO527A/ND
- 1 Q.OO531A/ND
- 2 Q.OO525A/ND
- 5 Q.OO529A/ND
- 6 Q.OO523A/ND
- 7 Q.OO547A/ND

B FIREPROOF
BULKHEAD AND
MAIN SPAR




- 9 Q.OO2423A/ND
- 10 Q.OO2421A/ND
- 4 Q.OO2425A/ND
- 3 Q.OO2427A/ND
- 1 Q.OO2441A/ND
- 2 Q.OO2443A/ND
- 5 Q.OO299A/ND
- 6 Q.OO300A/ND
- 7 Q.OO2439A/ND

C RIB No.2




- 4 Q.OO535A/ND
- 3 Q.OO537A/ND
- 1 Q.OO539A/ND
- 2 Q.OO541A/ND
- 5 Q.OO545A/ND
- 6 Q.OO543A/ND
- 8 Q.OO549A/ND

E MAIN SPAR



- 4 Q.OO2449A/ND
- 3 Q.OO2451A/ND
- 1 Q.OO2461A/ND
- 2 Q.OO2463A/ND
- 5 Q.OO2457A/ND
- 6 Q.OO2459A/ND
- 8 Q.OO2453A/ND

F RIB No.2



- 7 Q.OO2437A/ND
- D UNDERCARRIAGE
BAY
- B Q.OO2455A/ND

G UNDERCARRIAGE
BAY

J7

MAY '52

POWER PLANT INSTALLATION POWER PLANT ATTACHMENTS AND FITTINGS

K1

PIPE, PRESSURE,
CANOPY SEAL,
P.OO2156A

PIPE, AIR
COMPRESSOR
COOLING,
R.OO436A/ND

POWER PLANT FIRE
EXTINGUISHER SYSTEM:
PIPE L.OO1132A.
FOR DETAIL, SEE
PLATE No.K6

PIPE, AIR COMPRESSOR TO
BULKH'D, L.OO637A.
RELIEF VALVE
RV.10 (HYMATIC)

PIPE, OIL PRESSURE
TRANSMITTER
L.OO185A

PULLEY AS.104

FOR MOUNTING FRAMES
AND ATTACHMENTS, SEE
PLATE No.K5

PRESSURE-
REDUCING VALVE,
CANOPY SEAL,
AHO.19682
(DUNLOP)

*FIRE EXTINGUISHER BRACKET, L.OO826A. L.OO3553A
PIPE FROM FIRST JOINT TO FLANGE
L.OO3623A/ND
PIPE FROM BOTTLE TO FIRST JOINT
L.OO3627A/ND

FOR ENGINE COWLING,
SEE PLATE No.K2

R.OO433A

BRACKET
R.OO619A

FOR MISCELLANEOUS
FITTINGS, SEE PLATE No.K7

L.OO55A

FIRE EXTINGUISHER,
FRONT RING:
BOTTOM PIPE
L.OO3661A/ND
LH. PIPE
L.OO3657A/ND
RH. PIPE
L.OO3653A/ND.
FOR DETAIL, SEE
PLATE No.K6

CLIP AT ENGINE
END OF DUCT,
D.OO2469A.
CLIP AT BULKH'D
END OF DUCT,
D.OO2468A.
JOINT D.OO2465.
DUCT, PORT,
D.OO1997A/2
DUCT, ST'BD,
D.OO1996A/2

CONNECTOR
R.OO301

L.OO1060A

INSTALLATION FIRE
EXTINGUISHER SYSTEM,
*SEE BELOW

PIPE, GUN HEATING,
HOT AIR SUPPLY,
R.OO627A/ND.

FOR DETAILS OF
AIR PIPES AT ENGINE,
SEE PLATE No.K6

PIPE, GUN HEATING,
COLD AIR INLET,
R.OO628A/ND

R.OO302

K1


MAY/52

[K2]


POWER PLANT INSTALLATION ENGINE COWLING

[K2]


21.11.49



MAY '52



FRAME, IDENTIFICATION
LAMP WINDOW, LH.
L.OO936A




MOUNTING PLATE
LOO951A




CLIP, JURY STRUT SUPPORT,
R.OO112




ANCHOR, JURY STRUT,
L.OO458A




LOUVRE L.OO776



RAIL, HINGE, LOWER, L.OO66
(UPPER, L.OO65, SIMILAR)



WINDOW LH. L.OO1417
GASKET L.OO947 MASK L.OO943



TOGGLE FASTENER, DOOR,
L.OO116/1


K3

POWER PLANT INSTALLATION


ENGINE COWLING FITTINGS

K3


16.11.49




FRAME, IDENTIFICATION LAMP WINDOW, RH.
L.OO939A




MOUNTING RING L.OO949A.
PACKING RING L.OO945



WINDOW, RH. L.OO1418
GASKET L.OO946. MASK L.OO941



TOGGLE FASTENER L.OO53A/I
[L.OO1318A/I TO L.OO1323A/I AND
L.OO1345A/I TO L.OO1350A/I, SIMILAR]




L.OO1239A/ND

TIE ROD, COWL FASTENING,
L.OO438A



FASTENING
HOOK,
INSPECTION
DOOR,
L.OO127A




JURY STRUT
L.OO447A

K4

POWER PLANT INSTALLATION

ENGINE COWLING FITTINGS

K4




K5

POWER PLANT INSTALLATION


MOUNTING FRAMES AND ATTACHMENTS

K5


MAY '52




SHROUD, AIR COMPRESSOR COOLING,
R.OO444A



CLIP R.OO622A




ELBOW R.OO287A LH.
ELBOW R.OO288A RH.



CLIP R.OO167A
[R.OO211A SIMILAR]



BRACKET L.OO638
[POWER PLANT]



'T' PIECE L.OO784
[FRONT RING]

K6










POWER PLANT
AIR PIPES AT ENGINE, AND FIRE EXTINGUISHER FITTINGS

K6

VAMPIRE Mk 9

MAY '52

FLEXIBLE PIPES

 11 1/2" LONG, OVERALL REAR BEARING DRAIN, L.OOI141A	 L.OOI136A 26 1/2" LONG. L.OOI134A 19 1/2" LONG. L.OOI139A 22 3/8" LONG. OVERALL HYDRAULIC PUMP DRAIN, L.OOI136A, [L.OOI134A AND L.OOI139A, SIMILAR]	 8 3/4" LONG, OVERALL COMBUSTION CHAMBER DRAIN, L.OOI138A	 16 3/8" LONG, OVERALL GOVERNOR MAIN DRAIN, L.OOI142A
 25" LONG, OVERALL MINIMUM PRESSURE VALVE DRAIN, L.OO2203A	 16 1/2" LONG, OVERALL ACCUMULATOR DRAIN, L.OOI135A	 11 1/2" LONG, OVERALL FUEL DUMP VALVE DRAIN, L.OOI137A	 LOWER HALF OF FIREGUARD L.OO2340
 TRUNNION POST L.OOI33 [L.OOI34, SIMILAR]			 DRAIN PIPE, JET TUBE, L.OO954A
		 STIRRUP, SHORT TYPE, L.OO412	 STIRRUP, LONG TYPE, L.OO411

K7

POWER PLANT MISCELLANEOUS FITTINGS

K7

